Ordinance AGM-65E *"Maverick"*	Guidance LASER
Set A/G mode	**LF or HOTAS**
Set MASTER ARM to ARM	**LF or HOTAS**
Select MAV x2 for MAV DSPLY	**SMS**
- Check cooldown time (30 sec)	*SMS*
Select INST (or DLY#)	**SMS**
Select UFC to enter laser code	**SMS**
Select :CODE *(enter code)*	**UFC**
FLIR Startup ***(2 minutes)***	
FLIR switch to STBY	**R Arm**
Select FLIR	**DDI/AMPCD**
- ~~RDY~~ to STBY	*FLIR DDI*
FLIR switch to ON	**R Arm**
SCS to FLIR DDI	**mini-stick**
FLIR mode slave/plow	**2x Undes. buton**
LTD/R switch to ARM	**R Arm**
Set PTRK / ATRK *(scs toward FLIR DDI)*	**HOTAS**
TDC to select target	**mini-stick**
SCS to Mav feed DDI	**mini-stick**
UNCAGE seeker *(if desired)*	**HOTAS**
- ~~MAVF~~ to MAVF = Lock	*HUD*
WEAPON RELEASE to Lase	**HOTAS**
WEAPON RELEASE to Launch	**HOTAS**