Ordinance	Guidance
AGM-84E *"SLAM"* *(Target-of-Opportunity)*	**RADAR** *(TOO)*
Set A/G mode	**LF or HOTAS**
Set MASTER ARM to ARM	**LF or HOTAS**
Weapon Prep	**Required**
Select SLAM	**SMS**
Select DL13	**SMS**
Select STEP *(to desired missle station)*	**SMS**
- 01 GOOD and TIMING extinguished (3 min.)	*SMS*
Select WEP	**SMS**
Select SLAM *(to desired missle station)*	**SMS**
- SLAM under DL13 box	*SMS*
FLT to LOW / MED / HIGH	**SMS**
EFUZ to INST	**SMS**
Select SLAM DSPLY	**SMS**
REL TYPE to MAN	**SMS**
Select UFC	**SMS**
Select :DST *(activation distance from TGT)*	**UFC**
Deselect UFC *(to unbox)*	**SMS**
Target-of-Opportunity to A/G RADAR	
MODE to TOO	**SMS**
Select MSN	**SMS**
Select TOO1 / TOO2	**SMS**
SCS to RDR ATTK DDI	**Mini-stick**
Depress TDC, slew to TGT	**Mini-stick**
Select EXP2	**DDI**
Depress TDC, slew to TGT	**Mini-stick**
Select EXP3	**DDI**
Depress TDC, slew to TGT	**Mini-stick**
- TGT data transfered to ORP page	*SMS*
- TGT designations on HUD	*HUD*
Select RETURN *(to re-enter SMS page)*	**SMS**
- SMS and HSI visible	*DDI*
- SLAM is RDY	*SMS*
- MASTER ARM is ARM	*SMS*
- Verify release profile	*SMS*
Proceed to TGT	**HUD/HSI**
- TMR = IN RNG	*HUD/SMS*
WEAPON RELEASE	**HOTAS**

Post-Launch Actions	Required
- Terminal Attack Stage (TTS = 0)	*SMS/DL13*
Select FOV *(as required)*	**SMS/DL13**
Select A ANT *(as required)*	**SMS/DL13**
Depress and Slew TDC to select TGT	**Mini-stick**
Release TDC to lock TGT	**Mini-stick**