


WAGGLE NORTH APPROACH

CASE III RECOVERY

Enter Marshal Holding Pattern
Proceed Inbound Upon Clearance



Lead turn to Final by 2-4 degrees depending on wind effects by using TACAN bearing pointer.

Or, for a 90 degree turn use 10 percent of your groundspeed to TLAR the distance in NM.

NOTE: Distances are NOT to scale.