

DCS UH-60L V 2.0

BEFORE START CHECKLIST		POST ENGINE START CHECKLIST	
COLLECTIVE CHECK	DOWN	STABILATOR POSITION 35 DEGREE	CHECK
BATTERY SWITCH	ON	WARNING/ADVISORY/CAUTIONS PANEL	NO CAUTIONS <i>ADV POSSIBLE</i>
APU GENERATOR SWITCH	ON	BAROMETRIC PRESSURE	AS DESIRED
GENERATOR 1	ON	RADAR ALTIMETER LO BUG	AS DESIRED
GENERATOR 2	ON	RADAR ALTIMETER HI BUG	AS DESIRED
APU	ON	AUXILIARY FUEL TRANSFER MODE	OFF/AUTO
VERIFY APU START AND SYSTEMS ON	CHECK	BAROMETRIC PRESSURE	AS REQUIRED
INTERIOR LIGHTNING	AS DESIRED	AIR TO AIR REFUELING	
WINDSHIELD WIPERS	AS DESIRED	AN/ARC-164	SET TO TANKER FREQUENCY
AN/ARN-149 POWER SELECTOR	ON	AAR PROBE	CONTACT TKR EXTEND
AN/ARN-147 POWER SELECTOR	ON	PTT SWITCH	CONTACT TKR FOR PRECONTACT
AN/ARN-201 FUNCTION SELECTOR	AS DESIRED	AAR PROBE	RETRACT
COUNTERMEASURES DISPENSER MODE	AS DESIRED	PTT SWITCH	
FLARE AND CHAFF COUNTERS	CHECK	AFTER REFUELING AAR PROBRE	
AN/APR-39 POWER SELECTOR	ON	SHUTDOWN CHECKLIST	
TAIL WHEEL	LOCKED	COLLECTIVE	DOWN
AN/ASN-128 MODE	MGRS/LAT LONG	ENG 1 & 2 CONTROL LEVER	SET IDdle
PRESS ENT 2X		AN/ARN-149 POWER SELECTOR	OFF
AFCS AUTO CONTROL	ON	AN/ARN-147 POWER SELECTOR	OFF
AFCS BOOST	SQ ON	AN/ARN-201 FUNCTION SELECTOR	OFF
AFCS SAS1	ON	AN/ARC-201 SELECTOR	OFF
AFCS SAS2	ON	ENGINE 1 SELECTOR	OFF
AFCS TRIM	ON	ENGINE 2 SELECTOR	OFF
AFCS FPS	ON	WHEN ROTOR BLADES STOP	
AN/ARC-201 SELECTOR	ON	ENGINE 1 FSS	OFF
AN/AVS-7 POWER SELECTOR	AS DESIRED	ENGINE 2 FSS	OFF
START CHECKLIST		FOR DAP VERSION PRIOR TO ENGINE START	
WHEEL BRAKE	SET	PYLON SYSTEMS	AS DESIRED
ENGINE 1 FSS	DIR	PILON POWER SELECTORS	AS DESIRED
ENGINE 2 FSS	DIR	DOOR GUNNER POWER	AS DESIRED
AIR SOURCE SWITCH	APN	GUNNER CONTROL AUTHORITY	AS DESIRED
ENG 1 STARTER BUTTON	PRESS RELEASE		
ENG 1 CONTROL LEVER	IDLE		
VIDS	MONITOR RPM		
	MONITOR TGT		
ENG 2 STARTER BUTTON	PRESS RELEASE		
ENG 2 CONTROL LEVER	IDLE		
VIDS	MONITOR RPM		
	MONITOR TGT		
ENG 1 & 2 CONTROL LEVER	ADVANCE FULL		
VIDS	MONITOR RPM		
	MONITOR TRQ		
APU SWITCH	OFF		
FOR USE WITH UH-60L MOD V2.		09-22-2025	V 1.0