Ordinance AGM-88C *"HARM" (Self-Protect Mode)*	Guidance RADAR *(SELF)*
Set A/G mode	LF or HOTAS
Set MASTER ARM to ARM	LF or HOTAS
Set TAC EW page on right DDI	DDI
Select HARM	SMS
Select SP	SMS
Select emitter to track *(HARM TGT Seq.)*	HOTAS
WEAPON RELEASE	HOTAS