Ordinance Mk82/83/84	Guidance Unguided *(CCIP)*
Set A/G mode	LF or HOTAS
Set MASTER ARM to ARM	LF or HOTAS
Select 82B	SMS
Select PROG	SMS
MODE to CCIP	SMS
MFUZE to NOSE	SMS
EFUZE to VT / INST / DLY1 / DLY2	SMS
DRAG to FF / RET	SMS
Select UFC	SMS
Select :QTY *(total # released)*	UFC
Select :MULTI *(# simultaneously)*	UFC
Select :INT *(impact interval in ft.)*	UFC
30°- 45° dive	HUD
DIL vertical	HUD
Steer CCIP cross to target	HUD
Release when CCIP is on target	HUD