

## F-5E "Tiger II" QRT Start-Up Procedure

F-5E Start-up Checklist	Short Start-up
Set BATT to ON	RH
Set GENERATORS to ON	RH
Set BOOST PUMPS to ON	RH
COMMS: <i>Connect Air Supply</i>	Comms
COMMS: <i>Supply air to LEFT ENG</i>	Comms
- L Eng RPM $\geq 10\%$	RF
Push L ENG START	LH
Set L ENG to IDLE	HOTAS
- IDLE RPM (49 to 52%)	RF
COMMS: <i>Supply air to RIGHT ENG</i>	Comms
- L Eng RPM $\geq 10\%$	RF
Push R ENG START	LH
Set L ENG to IDLE	HOTAS
- IDLE RPM (49 52 %)	RF
COMMS: <i>Disconnect Air Supply</i>	Comms
Set AIRBRAKES to RETRACT	HOTAS
Set FLAP MODE to THUMB SWITCH	LH
Set Flap Thumb Switch to AUTO	HOTAS
Set DAMPERS to ENABLE	L ARM
Close CANOPY	RH
Set O2 SUPPLY to ON	RH
Set PITCH TRIM for Takeoff (6 clean - 9 heavy)	LF/Stick
Set ALT to 0 (for AGL)	LF
Set SAI to -3	LF
Set PAI to -3	LF
Set AUTO-BALANCE to LEFT LOW	RH
MASTER CAUTION Reset	RF
- Set Throttle to 85% to Taxi	
- Hold NWS when steering	
- Rotation speed = 145 (clean) - 190 (heavy)	
Set RADAR to STBY	L ARM
Set HSI to RUNWAY HDG (CRS knob)	LF
Extend NOSE STRUT	LF
Set FLAPS to AUTO	HOTAS
Set EJECT SEAT to ARMED	RH